


GPIB OPERATION


KEYBOARD COMMANDS



Keyboard equivalent commands

NON-KEYBOARD COMMANDS

PD,EM Set p.d. or e.m.f. mode
 EV,DV Enable or disable VARIABLE control
 SE,SD Store/poke enable or disable
 SQn SRQ (inhibit, error only, enable : 0,1,2)
 UC,LC Upper case or mixed case terminator strings
 WRc,r<CSD> Write data starting at column c, row r
 DS,ES,CS,RS Disable, enable, clear or restore screen
 PG Purge output buffer
 POn,n Poke data n into location m
 DUm,n,n As PO but only up to terminator or 64 bytes
 TF,TE Record seq. tone freq. or numbers and errors
 LF,EX Select <LF> or <ETX> with <EOI> as terminator
 ET,DT Enable or disable r.f. directional power head
 SP Suppress GPIB annunciators
 BX,n,m Put up soft key boxes of pattern n, length m
 BP Sound beeper



Character set using WR command

DATA TRANSFER


— when addressed to talk —

SV Send data string to restore current settings
 RDn Send reading or setting n, as below:

n	Reading	n	Setting
1	RF counter freq.	26	Seq. tone standard
2	RF power	27	RF gen. freq.
3	Mod. freq.	28	RF gen. level
4	Mod. level	29	AF gen. freq.
5	AF counter freq.	30	AF gen. level
6	AF level	31	Mod. freq.
7	Rx distortion	32	Mod. level
8	Tx distortion	33	RF Δ freq.
9	Mod. peak, dev. +	34	RF Δ level
10	Mod. trough, dev. -	35	AF Δ freq.
11	RF fwd. power	36	AF Δ level
12	RF refl. power	37	Mod. Δ freq.
13	VSWR, return loss	38	Mod. Δ level
14-25	Seq. tone 1-12		

39 Whole page readings and settings

ER Send code for last error detected
 VN Send software version number
 SK Send ASCII character for last key pressed



ASCII characters sent following SK command

MARCONI INSTRUMENTS LIMITED
 Longacres, St. Albans, Herts AL4 0JN, England.
 Telephone: (0727) 59292 Telex: 23350
 Fax: (0727) 57481

© Marconi Instruments Ltd 1985
 Printed in the UK

June 89

Marconi
 Instruments

RADIO COMMUNICATIONS

TEST SET 2955

0.4 to 1000 MHz

TRANSMITTER TESTING

Δ = see INCREMENTS

RF POWER METER

Press **Tx** and **SELECT** for required RF IN.

Sustained overload makes display flash and sounds alarm. Read power and frequency on display. Or enter Tx frequency:

e.g. **Tx** **FREQ** **1** **0** **MHz** and read offset.

MODULATION METER

Press **Tx** and **SELECT** for required RF IN.

Select modulation: **FM**, **AM** or **PM**

Select filter: **BAND PASS** (0.3 to 3.4 kHz) or **LOW PASS** (0.3 or 15 kHz).

Use **AF GEN OUTPUT** to modulate Tx if required.

Read a.m. depth or +/- deviation on display.

Monitor demodulated signal on internal loudspeaker or by earphones at ACCESSORY socket. Signal also available at DEMOD OUT socket.

AF GENERATOR

Press **Tx** **AF GEN** and connect UUT to **AF GEN OUTPUT**

Enter frequency followed by units terminator:

e.g. **FREQ** **1** **.** **2** **3** **4** **MHz** Δ

Enter level followed by units terminator:

e.g. **LEVEL** **5** **0** **MV** Δ

For 2-tone operation press **TONES** and follow menu.

DISTORTION METER (Tx)

Press **Tx** and **SELECT** for required RF IN.

Connect **AF GEN OUTPUT** to Tx modulating input.

Press **DIST N ON-OFF** until **DISTN** is displayed.

Select modulation: **FM**, **AM** or **PM**

and read % distortion.

RECEIVER TESTING

△ = see INCREMENTS

RF GENERATOR

Press **Rx**, **RF GEN** and **SELECT** for required RF OUT.
(BNC socket has 50 W reverse power protection.)

Enter frequency and level followed by units terminator:

e.g. **FREQ** **1** **2** **3** **.** **5** **MHz** △

and **LEVEL** **-** **3** **4** **dBm** △

Press **SET MOD** and enter modulating frequency:

e.g. **FREQ** **1** **.** **5** **KHz** **mV**

Enter a.m. depth: e.g. **LEVEL** **6** **0** **AM %** △

or f.m. deviation: e.g. **LEVEL** **5** **KHz** **mV** △

or φ.m. radians: e.g. **LEVEL** **2** **φM RAD** △

For ext. mod. connect modulating signal to **EXT MOD INPUT**

To switch off int. mod. enter **LEVEL** **0** (kHz, % or RAD).

For 2-tone int. mod. press **TONES** and follow menu.

Press **MOD ON-OFF** to switch int. or ext. mod. on or off.

AF VOLTMETER

Press **Rx** (and **AF GEN** for AUDIO TEST mode
– see AF GENERATOR for settings).

Connect UUT to **AF INPUT** (and **AF GEN OUTPUT** for AUDIO TEST).

Select filter: **BAND PASS** (0.3 to 3.4 kHz) or **LOW PASS** (0.3 or 50 kHz).

To read a.f. volts press **AC DC** to display AC.

To read d.c. + a.f. volts press **AC DC** to display DC

(50 kHz l.p.f. is automatically selected).

Press **DIST N ON-OFF** to read dBV. Then press **dB** to read dBr.

DISTORTION METER (Rx)

Press **Rx** and **SELECT** for required RF OUT.

Set generator frequency – see RF GENERATOR.

Connect Rx input to RF OUT and output to **AF INPUT**

Press **DIST N ON-OFF** to display DISTN (a.c. coupling and 0.3 to 3.4 kHz b.p.f. are automatically selected) and read % distortion.

For noise measurement press **SINAD S/N** to read SINAD or S/N.

DUPLEX TESTING

Press **DUPLEX** and **SELECT** to display ONE or TWO PORT.

Set generator frequency, level and modulation (see RF GENERATOR) and Rx frequency.

Connect Rx input to RF OUT (N for 1-port or BNC for 2-port operation).

Select Tx channel.

Connect Tx output to RF IN (N for both 1- and 2-port operation).

Connect **AF GEN OUTPUT** to Tx modulating input.

Connect Rx output to **AF INPUT**

Press **DIST N ON-OFF** or **SINAD S/N** and read Rx distortion, SINAD or S/N.

TONES ENCODING/DECODING

(Tone standards : CCIR, ZVEI, DZVEI, EEA/EIA, and User Defined)

Transmitter test

Press **Tx** and **SELECT** for type N RF IN, and turn on Tx.

Press **TONES** to display TONES STANDARD MENU.

Press MODE key indicated by menu to select required tone standard, user defined standard or 2-tone operation.

Receiver test

Press **Rx** and **SELECT** for required RF OUT.

Press **TONES** to display TONES STANDARD MENU.

Press MODE key indicated by menu to select required tone standard, user defined standard or sub-audible tone.

Duplex mode

Follow instructions under DUPLEX TESTING.

Press **TONES** to display TONES STANDARD MENU.

Press MODE key as for 'Receiver test'.

OSCILLOSCOPE DISPLAYS

Press **SCOPE** and set **INTENSITY** and **POSITION**

Press **◀▶** or **▶▶** to change horizontal trace expansion

and **◀▶** or **▶▶** to change vertical trace expansion.

Select **REP** for repeated trace on auto-trigger or **SINGLE** for one sweep in storage mode.

INCREMENTS

Stepped increments or decrements can be selected for:
AF GEN function – frequency and level,
RF GEN function – frequency, level, and modulation units.

Enter step size followed by units terminator:
e.g. for frequency increments:

FREQ **Δ INCR** **5** **0** **0** **MHz**

or for level increments:

LEVEL **Δ INCR** **.** **2** **dB**

or for modulation increments:

SET MOD **LEVEL** **Δ INCR** **1** } **AM %**
OR **KHz** **mV**
OR **φM RAD**

Then use **FREQ ↑** or **LEVEL ↑** for single steps
FREQ ↓ or **LEVEL ↓**

or **VARIABLE** for continuous steps of smallest increment allowed.

STORE AND RECALL

To save settings press **STORE** or **RECALL** followed by identity digits 01 to 38. **RECALL** 00 restores settings after switch-off.

HELP KEY OPERATION

Press **HELP** to display HELP menu.

Press MODE key indicated by menu for help in TESTING, CHANGE PARAMETERS or SELF TEST.

ERROR CODES IN SELF TEST

Code	Sig. Gen. frequency	Code	Sig. Gen. power (¼mW)
10	Pass	20	Pass
11,12	20 MHz high, low	21,22	300 MHz low, high
13,14	111 MHz high, low	23,24	849 MHz low, high
15,16	218 MHz high, low	25,26	20 MHz low, high
17,18	340 MHz high, low	27,28	20 MHz (¼ mW) low, high
19,1A	480 MHz high, low		
1B	Counter failure		

Code Mod. freq. and level

30	Pass
31,33,34	400 Hz f.m.: freq. fails, level low, high
32,35,36	1 kHz f.m.: freq. fails, level low, high
37,38	1 kHz a.m.: level low, high
39,3A	1 kHz φ.m.: level low, high